taylordolman
tel: 0845 838 0600
email: info@taylordolman.com

GB/US ..... GH1 Ceiling Hoist

Vers. 3.00

CE



Guldmann™

GH1 Ceiling Hoist

Item no.
552xxx

1.00 . . . . . Purpose and use 3
1.01 . . . . . Manufacturer 3
1.02 . . . . . Purpose 3
1.03 . . . . . Important/Precautions 3
1.04 . . . . . Load limits on GH1 system 4
1.05 . . . . . Unpacking and Preparation 4
1.06 . . . . . Placing a new GH1 hoist in an existing rail system. 5
1.07 . . . . . Power supply 5
1.08 . . . . . Installation of the lifting hanger before use 6
1.09 . . . . . Lifting sling 7
1.10 . . . . . Swing kit. 9
1.11 . . . . . Using swing kit in doorway 10
1.12 . . . . . Exchange of side cover 11

2.00 . . . . . Description of functions 11
2.01 . . . . . Pictograms 12
2.02 . . . . . Indicator lamps and audio signals 12
2.03 . . . . . Operation 12
2.04 . . . . . Safety functions 14
2.05 . . . . . Accessories 15

3.00 . . . . . Transport and storage. 16

4.00 . . . . . Maintenance and storage 16
4.01 . . . . . Cleaning. 16
4.02 . . . . . Storage 16
4.03 . . . . . How to prevent/avoid corrosion? 16
4.04 . . . . . The owner's daily maintenance duty 17
4.05 . . . . . Disposal of the GH1 including battery 17

5.00 . . . . . Service and lifetime 17
5.01 . . . . . Lifetime 17
5.02 . . . . . Safety/service inspections 17
5.03 . . . . . Troubleshooting 18

6.00 . . . . . Classification 18

7.00 . . . . . Technical specifications 20

8.00 . . . . . EC-Declaration of conformity 22

. . . . . USA and countries outside the EU 23
A. . . . . Users guide 23
B. . . . . Warranties 23

© Guldmann GB/US-1706/03/2011 • # 550865

1.00 Purpose and use

1.01 Manufacturer

V. Guldmann A/S
Graham Bells Vej 21-23A
DK-8200 Aarhus N
Tlf. + 45 8741 3100
Fax + 45 8741 3131
www.guldmann.com

1.02 Purpose

GH1 is a ceiling-mounted hoist which covers the need for lifting or moving a person with disabilities in the home care sector, nursing homes, rehabilitation centres, riding schools and swimming pools.

Conditions for use

The use of the GH1 is subject to the following:

- The GH1 should only be used by trained personnel.
- The maximum nominal load, 175 kg (385 lbs), 205 kg (450 lbs), respectively, must not be exceeded *(section 1.04)*.
- The instruction offered by Guldmann to all customer groups in connection with the purchase of a ceiling-mounted hoist has been received.
- The helper pays attention to the well-being of the user when using the hoist.
- The hoist is used in rail systems which are installed, tested and approved according to DS/EN 10535 and Guldmann's stipulations.
- Only technicians who have been certified by Guldmann may install and test the rail systems.
- The hoist is used with a Guldmann lifting hanger *(section 1.08)*.
- The hoist is used with a Guldmann lifting sling or with other suitable slings *(section 1.09)*.

1.03 Important/Precautions

- Read the instructions carefully before using the GH1 and in connection with cleaning and service of the hoist.
- The GH1's maximum load must never be exceeded.
- The GH1 may only be used to lift a person.
- The red strap for the emergency stop and the emergency lowering must be adjusted to the helper's reach, and must not be removed.
- If the GH1 fails while in use, stop using the hoist and contact the Guldmann Service Team for repair.
- The GH1 is controlled by a microprocessor PCB, which can be damaged by static electricity if touched without the necessary precautions, *(see point 1.07)*
- The electronics may only be serviced by Guldmann approved service technicians.
- For safety reasons the side cover may only be dismantled when the emergency stop is activated *(see point 2.04)*.

© Guldmann GB/US-1706/03/2011 • # 550865

Re: EMC
If electromagnetic or other influences occur between this product and other products, these products must not be used together.

1.04 Load limits on GH1 system

Read the label which indicates the maximum load limits for each component. The component, e.g. lifting hanger, lifting sling, etc. labelled with the lowest load limit determines the maximum load limit for the entire system.
This maximum load limit must not be exceeded.
Please note that the max load may change when different components are used, such as lifting hangers, lifting slings, etc.

1.05 Unpacking and Preparation

Visual check of the GH1
If the GH1 is thought to be damaged upon reception, the GH1 must not be used before it has been checked and approved by a qualified person or the Guldmann Service Team.



Contents of the box

1. GH1 hoist
2. Hand control
3. Transformer
4. Charging station
5. Side covers
   (2 sets with 4 designs)
6. Manual
7. Label for rail system

Button for reset of emergency stop
GH1 is delivered with the emergency stop activated in order to ensure that the battery is not being discharged during long-term storage. Reset the emergency stop by pressing the “RESET” button on the bottom of the hoist *(see point 2.04)*.

Mounting of side cover
GH1 is standard delivered with side cover in 4 different designs.
Before starting to mount the side cover it is important, for safety reasons, to make sure that the emergency stop is activated *(see point 2.04).*
The chosen side covers are fitted on the side of GH1 by bending the cover slightly and placing it in the groove at the side of GH1.



© Guldmann GB/US-1706/03/2011 • # 550865

1.06 Placing a new GH1 hoist in an existing rail system

Please notice, when placing a new GH1 hoist in an existing rail system it must be ensured that:

- The rated max load of the rail system, must be equal or higher than the max load of the new hoist.
  - If there is no max load mentioned on the rail system, the rail system must then be checked according to the guideline in the installation manual (distance between bracket according to max load).
  - If the brackets are not visible, then a load test with 1,5 x max load of the hoist must be performed minimum 20 min. During the test the deflection of the rails must not be higher than 1/200 of the length of the rail.
  - If it is not possible to do any of the above mentioned, please contact Guldmann or their representative.

- If the rail system can not be rated to the same max load as the hoist, then extra brackets must be installed according to the installation manual (distance between bracket according to max load).

1.07 Power supply

GH1 is equipped with a battery that requires regular recharging. The power supply for the transformer and the charging station must be connected by Guldmann Service Team or by a qualified engineer.
The transformer supplied must ***always*** be used.

Safety concerning static electricity (ESD)
Service technicians and installers ***must*** use an ESD-safety package consisting of a mat, a ground wire, and a bracelet.
The technician/installer connects the mat to a grounding point, for instance a radiator or a water pipe. The technician/installer must then put on the bracelet and connect it to the mat. If it is not possible to find a grounding point, the mat and the bracelet must be used as a minimum.
Only then is it allowed to work with the PC Board or components where it is possible to come into contact with the PC Board.

Class I equipment
Fixed rail systems are class I equipment and ***must*** be installed by a qualified technician or by Guldmann Service Team.
Equipment is disconnected from Supply Mains by breaking the mains breaker switch.

Class II equipment
Mobile equipment is class II epuipment (marked with double-encassed symbol) and can be connected to the mains direct by the user.
Equipment is disconnected from Supply Mains by detaching the mains plug from the wall outlet.

© Guldmann GB/US-1706/03/2011 • # 550865

1.08 Installation of the lifting hanger before use

Lifting hangers from other manufacturers
Guldmann shall not be liable for faults or accidents that may occur as a result of using lifting hangers made by other manufacturers.

If there is any doubt about the selection or use of a lifting hanger, please contact your supplier.

The lifting hanger can be installed to the lifting strap without the use of any tools.

1. Hold the lifting hanger in the right hand and press the yellow button using the thumb as shown *(Fig. 1)*.

2. Insert the strap attachment in the slot on the lifting hanger top cover with the open side facing down *(Fig. 2a, 2b)* and release the yellow button *(fig. 2c)*.

3. Rotate the strap attachment to a vertical position *(fig. 3)*.

   Check that the yellow button has returned to its locked position by checking that it is flush with the cover of the lifting hanger and that the strap attachment can rotate freely.


Fig. 1


Fig. 2a


Fig. 2b


Fig. 2c


Fig. 3

© Guldmann GB/US-1706/03/2011 • # 550865

1.09 **Lifting sling**

A lifting sling with four to eight lifting straps designed for mounting on hooks should be used when using a Guldmann lifting hanger. Place the straps on the hooks. Make sure that the rubber safety catch returns to its start position, so the straps can not unintentionally fall off.

Slings made by other manufacturers

Guldmann shall not be liable for faults or accidents that may occur as a result of using lifting slings made by other manufacturers.

If there is any doubt about the selection or use of a lifting sling, please contact your supplier.

Guldmann shall not be liable for faults or accidents due to incorrect use of the lifting sling, or for reasons of inadequate attention on the part of the carer or user.

Attaching the lifting sling

Place the straps from the lifting sling on the hooks on the lifting hanger. Start with the uppermost set of straps (from the back) and then take the lowest set of straps (from the legs).



Important!

Be careful when applying the lifting sling. Check that the straps have been pulled completely through the rubber safety catch and into place in the lifting hanger's hooks before starting lifting the user.

© Guldmann GB/US-1706/03/2011 • # 550865

Lifting to and from a seated position
When lifting a user from e.g. a wheelchair, move the GH1 towards the person to be lifted. The lifting hanger should be at the same height as the user's chest and should not be moved further in over the user than to approximately mid-thigh position.
Place the lifting hanger parallel to the user's shoulders.
Place the lifting sling behind the user's back between the back of the chair and the user's back. The center marks of the lifting sling should follow the user's spine.
Lead the leg straps along the outer sides of the user's shins and beneath the thighs between the hollow of the knees and the hip joints. Cross the leg straps in front of the user.
All four lifting straps are now ready to be attached. The lifting sling can now be mounted on the lifting hanger.

Lifting to and from lying position in bed
Bring the lifting hanger over the centre of the person to be lifted. Place the lifting hanger parallel to the user's shoulders.
Turn the user onto his or her side. The Basic High sling should be placed so that its top is at the same height as the top of the user's head. Now position the sling over the user so that the center marks follow the user's spine. Turn the user onto his or her back and pull out the remaining part of the lifting sling. Place the leg straps beneath the user's thighs and cross them. All four lifting straps are now ready to be attached and the lifting sling can now be mounted on the lifting hanger. It is an advantage to elevate the head of the bed so that the user is sitting up.

For further information, please refer to the user manual for the lifting sling in question.

Important!
Only persons who have received competent instruction regarding the use of lifting equipment and fitting of slings should use the hoist.

Plan the move. Avoid leaving the user in the lifting sling unattended.

The GH1 lifts quickly and powerfully. Before lifting, check that the user is completely free of his/her surroundings. The user's head, arms, hands and feet must not be in danger of becoming trapped. Be careful with any tubes and wires that are attached to the user.
Check that the hand control and hand control cable is free of hanger, user and other object before the hoist is activated up or down moved.

If the hoist is used correctly, the user should only be lifted to the extent that she/he is clear of the surface and should be moved at this height.

© Guldmann GB/US-1706/03/2011 • # 550865

1.10 Swing kit

The swing function is used in conjunction with a transfer e.g. through a door from one lifting module to another.

Note: *The swing adapter must be ordered separately.*

Fig. 1

Installation of swing adapter

1. Before starting a lift involving a swing transfer the swing adapter *(Fig. 1)* must be installed on the lifting hanger. *(fig. 2 til 5)*.


Fig. 2

2. Hold the lifting hanger in the right hand and press the yellow button using the thumb *(fig. 2)*.


Fig. 3a

3. Insert the swing adapter in the slot on the lifting hanger top cover with the open side facing down *(Fig. 3a, 3b)* and release the yellow button.


Fig. 3b

4. Rotate the swing adapter to a vertical position *(fig. 4)*.

   Check that the yellow button has returned to its locked position by checking that it is flush with the cover of the lifting hanger and that the swing adapter can rotate freely.


Fig. 4

5. Install the strap attachment to the swing adapter by sliding the open side of the strap attachment over the flat area of the swing adapter *(fig. 5)*.


Fig. 5

6. Rotate the strap attachment and ensure that it moves up on the circular portion of the swing adapter *(fig. 6)*.


Fig. 6

© Guldmann GB/US-1706/03/2011 • # 550865

1.11 Using swing kit in doorway

1. Bring the two hoist as close together as possible. Adjust the height of the lifting hanger on hoist B so that the transfer can be done without the user touching the floor during the transfer from one hoist to another.

2. Take the free lifting strap from hoist A and secure it to the swing adapter on the lifting hanger *(see 1.10 figures 5 and 6)*.
   In order to lower the free lifting strap on hoist A a slight pull must be applied to the strap.

3. Lower the lifting hanger using hoist B while lifting the strap on hoist A to perform the swing transfer. The transfer has been completed when there is no load on the lifting strap on hoist B.

4. Disconnect the lifting strap on hoist B from the lifting hanger and raise the strap on hoist B out of the way.

5. Move the lifting hanger from hoist A to operating height and the doorway transfer is complete.

   Note: There must be a load on the lifting strap corresponding to the weight of Guldmann's lifting hanger before GH1's lowering function will operate.



© Guldmann GB/US-1706/03/2011 • # 550865

1.12 Exchange of side cover

If you want to change the appearance of GH1, the side cover can be exchanged or turned. Before starting to mount the side cover it is important, for safety reasons, to make sure that the emergency stop is activated *(see point 2.04).*

The side cover is dismantled by inserting for instance a flat screwdriver in the opening between the groove and the cover and tilt the cover upwards and out. The side cover is fitted on the side of GH1 by bending the cover slightly and placing it in the groove on the side of GH1.



2.00 Description of functions

Information panel on the GH1 bottom surface.



© Guldmann GB/US-1706/03/2011 • # 550865

2.01 Pictograms

Emergency stop

Emergency lowering function

RESET Reset emergency stop

Danger - rotating parts

2.02 Indicator lamps and audio signals

Status	Indicator lamps	Audio signals	Possible GH1 Functions		
			Up	Down	Emergency lowering
Off – stand by	Off				
All OK	Green		✓	✓	✓
Low battery	Yellow		✓	✓	✓
Fault on hoist	Yellow	Beeps at button activation			✓
Battery critical low	Yellow	Beeps at button activation		✓	✓
Over load	Yellow	Beeps at button activation		✓	✓

2.03 Operation

Hand control
The GH1 is switched on automatically when a button on the hand control is pressed.

The GH1 is switched off automatically after approx. 8 minutes without activation.



GH1
1. Lift
2. Lower

Note: There must be a load on the lifting strap corresponding to the weight of Guldmann's lifting hanger before GH1's lowering function will operate.

© Guldmann GB/US-1706/03/2011 • # 550865

Charging / connection
GH1 is recharged when the hand control is placed in the charging station. Always leave the hand control in the charging station when GH1 is not in use. This guarantees GH1 functionality and maintains the battery to ensure a long lifetime.

The transformer must be connected and switched on before charging can take place. A green indicator lamp on the transformer indicates it is connected and switched on.

Tilt the hand control and place it on the two pins on the charging station.Then push the rubber handle into the opening of the charging station. A click indicates that the hand control is placed correctly.



The indicator lamp on the bottom of the hoist turns yellow if the charge status becomes low. The GH1 then has a limited number of lifts available at a time and must be recharged.

Placing of the hand control
When GH1 is not in use the hand control must always be placed in the charging station. The hand control can also be placed on the lifting hanger if this is necessary in connection with a transfer.



© Guldmann GB/US-1706/03/2011 • # 550865

2.04 Safety functions

The emergency stop and emergency lowering device should only be used in an emergency. In the event that it is necessary to use the safety functions, the fault must be identified and rectified before the GH1 is taken into use again. Please contact your supplier.

Emergency stop and lowering strap

The red strap has the following functions:

- One pull: Emergency stop is activated.
- Constant pull: Emergency lowering is activated.







Emergency stop

If the GH1 does not stop/react to the hand control when the GH1 is in use, pull the red strap and the lifting/lowering functions (except emergency lowering) are deactivated.
When the emergency stop is activated, the hoist will not function. The green lamp is switched off.

Reset emergency stop

Reset the emergency stop by pressing the yellow button on the bottom of the hoist.



The yellow button that appears when the emergency stop is pulled, must be pressed manually before the GH1 is ready for use.
After deactivating the emergency stop, activate the hand control twice.

Emergency lowering function, electric

If the GH1 fails, the electrical emergency lowering function is used to lower the user safely. The emergency lowering function is operated by a constant pull on the red strap that is used for the emergency stop.

When releasing the red strap, the emergency lowering function will be replaced by the emergency stop.

© Guldmann GB/US-1706/03/2011 • # 550865

2.05 Accessories

Guldmann – Lifting slings and hangers
Obtain a product catalogue from Guldmann, or see our product range at www.guldmann.com where it is also possible to watch a video about the use of lifting slings and to download user manuals for our products.

Extension strap
The extension strap is used where the distance between the lower part of the rails and the floor exceeds 3.5 m. The extension strap is available as an accessory.

Swing adapter
The swing function is used in conjunction with a transfer, e.g. through a door from one lifting module to another.

Turntable
The turntable is used in rail systems where the hoist needs to run in several directions.



The GH1 hoist is placed in the center of the turntable. By pressing the switch, the turntable rotates 90°. Press again, and the turntable returns to the first position.

Safety
This product is mechanically protected against derailing and jamming.

Combi-lock, manual and electric
The Combi-lock is used when a single track rail system is to be linked up to a room-covering rail system, or when two room-covering rail systems need linking.



The Combi-lock ensures that the two systems are locked together in situations such as transfer from a single track rail system in a bedroom to a room-covering system in a bathroom.



The Combi-lock is available as an electric or a manual model. It is activated by either pressing the switch or pulling on the cord.

Safety
This product is mechanically protected against derailing and jamming.

© Guldmann GB/US-1706/03/2011 • # 550865

Battery
NiMH Battery 24V/2800mAh, Guldmann type number 550574.

Transformer
Transformer, Class 1, Guldmann item number 550200
Transformer, Class 2, Guldmann item number 550269 (EU),
550268 (US/CAN)

3.00 Transport and storage

Guldmann recommends that the GH1 is always transported and stored in the original packaging.

Key to symbols on the GH1 packaging:



The GH1 should be stored at:
– Temperatures between -10 and +40°C / 14 and 104°F
– A relative air humidity of between 30 and 70 %
– An air pressure of between 700 and 1060 hPa
– This side up

4.00 Maintenance and storage

4.01 Cleaning

Clean the GH1 with a damp cloth and mild handwash detergent.
Do not use strong acids, bases or alcohol to clean the GH1. Never clean GH1 in an autoclave.

4.02 Storage

See 3.00
For long-term storage of GH1 the emergency stop must be activated. This ensures that the battery is not being discharged.

4.03 How to prevent/avoid corrosion?

When the GH1 is mainly used in a corrosive environment, e.g. swimming pool, the hoist must be ordered with a special corrosion-preventive surface treatment.

© Guldmann GB/US-1706/03/2011 • # 550865

4.04 **The owner's daily maintenance duty**

Check the lifting sling for wear and damage before use.
Do not use the lifting sling if it is damaged or defective.
Do not use GH1 if the lifting strap or the rubber safety catch of the lifting hanger are damaged or defective.
Contact your supplier and order a new lifting sling or a replacement of the lifting strap. Replacement of the lifting strap must only be performed by the Guldmann Service Team or by a qualified technician in accordance with Guldmann's instructions.

4.05 **Disposal of the GH1 including battery**

Local and national regulations on environmentally correct recycling must be observed. Batteries (type NiMH) must always be delivered to an approved recycling point.

5.00 Service and lifetime

5.01 **Lifetime**

The GH1 has an expected lifetime of 15 years, on the condition of correct use and correct service inspections, see section 5.02.

Replacement of components

Replacement of batteries, PCBs and lifting straps must be performed by a qualified service technician or the Guldmann Service Team.

5.02 **Safety/service inspections**

In accordance with international standard EN/ISO 10535 "Hoist for the transfer of disabled persons – Requirements and test methods" an inspection should be performed on the hoist at least once a year.
Guldmann recommends that regular safety/service inspection is performed at least once a year with regard to the pattern of usage.

Inspection of the GH1 must be performed by a qualified service technician or the Guldmann Service Team.
In connection with the purchase of the GH1, Guldmann or your supplier may offer a service agreement for this inspection.

During the safety/service inspection a report must be prepared on what was checked and replaced. Parts that are worn or defective must be replaced with new parts from Guldmann. Spare parts drawings and documentation can be obtained from the manufacturer or supplier.

Documentation/checklist regarding safety/service inspection can be obtained from the manufacturer or supplier.

© Guldmann GB/US-1706/03/2011 • # 550865

5.03 Troubleshooting

The GH1 does not respond to the hand control's keys

1. Check that the emergency stop is not activated *(see section 2.04)*.
2. Check that GH1 has power supply and that the battery is recharged *(see section 2.02)*.
3. Check that the transformer is switched on and connected to the charging station.
4. Place the hand control in the charging station and recharge GH1 *(see section 2.03)*.
5. Contact the Guldmann Service Team if the fault cannot be found and corrected.

6.00 Classification

CE-marking

Type B in accordance with IEC/EN 60601-1

Read the manual before use

Must not be disposed of as standard household waste, must be recycled.

Class 1 equipment . . . . . Permanent installation with protective ground
Class 2 equipment . . . . . Non-permanent installation without protective ground

The equipment is not suitable for use in the presence of flammable mixtures.

Degree of protection against harmful ingress of liquids (water)

Lifting module. . . . . IP 44
Hand control. . . . . IP 44
Charging station. . . . . IP 20
Transformer . . . . . IP 20

© Guldmann GB/US-1706/03/2011 • # 550865

Examples of labels

Lifting module





Transformer Class 1



Transformer Class 1 (PSE)

Transformer Class 2
Use within US/CAN



Transformer Class 2
Use within EU

Lifting hanger

Hand control



© Guldmann GB/US-1706/03/2011 • # 550865

7.00 Technical specifications

GH1 Lifting modules, configurations									
Guldmann hoist type	Product line	Load in kg	Number of lifting straps	Number of lifting motors	Number of horizontal drive motors	Scale module	CLM module	Service module	User interface
GH1	(x)	xxx	x	x	x	x	x	x	x
GH1		175	1	1					Hand control : 0
		205	1	1					

Example: GH1 200 110 0000

GH1		**200**	**1**	**1**	**0**	**0**	**0**	**0**	**0**



© Guldmann GB/US-1706/03/2011 • # 550865

Functions

Lifting capacity, SWL . . . . . 175 kg (385 lbs), 205 kg (450 lbs)
Operation . . . . . Hand control
Sound level . . . . . .52 dB (A)

Lifting speed

85 kg (187 lbs) load . . . . . 30 mm/sec.
150 kg (330 lbs) load . . . . . 30 mm/sec.
Max capacity load, SWL . . . . . 30 mm/sec.
Max. 5 kg (11 lbs) load . . . . . 60 mm/sec.

Weight and materials

SWL . . . . . 175 kg (385 lbs), 205 kg (450 lbs)
Own weight . . . . . 8.0 kg (17.6 lbs)

Covers, top and bottom . . . . . Impact-resistant UL 94 V-0 flame
. . . . . .retardant recyclable plastic

Dimensions

A . . . . . .580 mm
B . . . . . .350 mm
C . . . . . .156 mm
D . . . . . .184 mm
E, min. . . . . .82 mm
F, min . . . . . .415 mm
G . . . . . .2500 mm
Depth of hoist . . . . . .194 mm



© Guldmann GB/US-1706/03/2011 • # 550865

Safety

Emergency stop . . . . . Yes
Emergency lowering device . . . . . Yes, electrical
Control of lifting strap . . . . . Yes
Cut-off angle . . . . . 45° along the rail
. . . . . 10° across the rail

Electronics

On/off . . . . . Automatic when used. Soft start/stop
Overload protection . . . . . Automatic
Low battery protection . . . . . Automatic
Power supply . . . . . 33 V AC, 2.5 A
Supply voltage, transformer . . . . . 100-115/230 V AC, 50-60 Hz

Battery . . . . . 24 V NiMH
SWL: 175 kg (385 lbs), 205 kg (450 lbs) . . . . . 2.8 Ah

Continuous operation with short time loading with
3 hours without recharging . . . . . 10/90 % (2 min. operation/18 min. pause)

Max number of lifts in series with:
85 kg (187 lbs) . . . . . 55/1000 mm
SWL: 175 kg (385 lbs), 205 kg (450 lbs) . . . . . 28/1000 mm

Max charging time at 25ºC (77ºF):
SWL: 175 kg (385 lbs), 205 kg (450 lbs) . . . . . 3 hours

Operating temperature . . . . . 10°C - 35°C (50°F - 95°F)

Degree of protection against harmful ingress of liquids (water)

Lifting module . . . . . IP 44
Hand control . . . . . IP 44
Charging station . . . . . IP 20
Transformer . . . . . IP 20

8.00 EC-Declaration of conformity

The products are manufactured in compliance with the Council Directive 93/42/EEC of 14 June 1993 – with amendments, as medical device class 1.

© Guldmann GB/US-1706/03/2011 • # 550865

USA and countries outside the EU

A. **Users guide**

Before using the product, read the entire operation manual including all warranties.

B. **Warranties**

The Guldmann lifting equipment is designed to be used for the lifting, transferring, and transporting of a person with a physical handicap who are not able to physically self transfer or who are temporarily incapacitated by illness, anesthesia or other causes.

This lifting equipment is designed to relieve the users, their caregivers, and nursing personnel in the task of lifting elderly or disabled people, thereby minimizing the risk of back injury during such lifting and transfer operations. If the product is used irresponsibly or for any use other than that described above or in the enclosed written instructions, the manufacturer's warranty will be nullified and rendered void.

There are no warranties which extend beyond the description in the enclosed written instructions.

Guldmann warrants that its lifting equipment is free from defects in materials and workmanship under normal use. Guldmann warrants that the lifting equipment itself will perform substantially in accordance with the specifications set forth in the documentation provided with the equipment.

The above express warranties are made for a period of 365 days from the date the lifting equipment is delivered to you as the first user.

The distributor will replace any lifting equipment which proves defective in materials or workmanship, without additional charge, on an exchange basis.

The distributor will either replace or repair without additional charge any Guldmann lifting equipment that does not perform in substantial accordance with the specifications of the document.

Guldmann does not warrant that the functions contained in the lifting devices will meet your requirements or that the operation of the services will be uninterrupted or error-free. The warranty does not cover any of the part of the lifting equipment which has been subject to damage or abuse by you. The warranty does not cover any part of the lifting equipment which has been altered or changed in any way by you or others. Guldmann is not responsible for problems caused by changes in the operating characteristics of the operating system which are made after the delivery of the lifting equipment.
Any implied warranties including any warranties of merchant ability or fitness for a particular purpose are limited to the term of the express warranties.

© Guldmann GB/US-1706/03/2011 • # 550865

Guldmann shall not in any case be liable for special, incidental, consequential, indirect or other similar damages arising from any breach of these warranties even if Guldmann or its agent has been advised of the possibility of such damages.

You must call Guldmann or your distributor for an authorization to return any defective item during the warranty period. If your distributor is unable to correct your problem by telephone, you will be provided with a return authorization number and address for returning the defective item for warranty service or replacement. You must insure any defective item being returned because Guldmann does not assume the risk of loss or damage while in transit. Do not return items or warranty service to Guldmann.

The warranties set forth are in lieu of all other express and implied warranties, whether oral, written or implied, and the remedies set forth above are your sole and exclusive remedies. Only an authorized officer of Guldmann may take modifications to this warranty, or additional warranties binding on Guldmann. Accordingly, additional statements such as advertising or presentations, whether oral or written, do not constitute warranties by Guldmann and should not be relied upon as such. The warranty gives you specific legal rights, and you may also have the other rights which vary from state/country.

© Guldmann GB/US-1706/03/2011 • # 550865

© Guldmann GB/US-1706/03/2011 • # 550865

Time to care

taylordolman

tel: 0845 838 0600
email: info@taylordolman.com